



SANTA · SANGRE · SUPPLY

MACCHINE A BOBINA

Dopo le prime 10 ore di utilizzo la macchina si sarà assestata nella tensione della molla, procedere dunque chiudendo di 1/4 di giro la vite di contatto.

Ripetere poi l'operazione circa una volta al mese, o qualora se ne sentisse l'esigenza (surriscaldamento bobine, progressiva necessità di aumento voltaggi).

MACCHINA ROTATIVA SLIDER 22mm (4.5mm STROKE)

Utilizzare con il polo positivo clipcord in basso.

Voltaggi consigliati (parametri eikon):

3V DOTWORK

5V COLORAZIONE

5.5V SFUMATURA

N.B. VOLTAGGIO MASSIMO 6V

Lubrificare lo slide una volta al mese con l'apposito superlube in dotazione.

MACCHINA ROTATIVA SLIDER 27mm (4.2mm STROKE)

Utilizzare con il polo positivo clipcord in basso.

Voltaggi consigliati (parametri eikon):

3.5V DOTWORK

6.5V COLORAZIONE

7V SFUMATURA

N.B. VOLTAGGIO MASSIMO 9V

Lubrificare lo slide una volta al mese con l'apposito superlube in dotazione.

MACCHINA ROTATIVA SH808 (4.5mm STROKE)

Utilizzare con il polo positivo clipcord in basso.

Voltaggi consigliati (parametri eikon):

3.5V DOTWORK

6.5V COLORAZIONE

7V SFUMATURA

N.B. VOLTAGGIO MASSIMO 9V

Lubrificare il pistone una volta al mese con un olio tecnico (es olio di vaselina).

MACCHINA ROTATIVA DIRECT 27mm (4.5mm/3.7mm STROKE)

Utilizzare con il polo positivo clipcord in basso.

Voltaggi consigliati (parametri eikon):

3.5V DOTWORK

6.5V COLORAZIONE

7V SFUMATURA

N.B. VOLTAGGIO MASSIMO 9V

MACCHINA ROTATIVA DIRECT 22mm (4.5mm STROKE)

Utilizzare con il polo positivo clipcord in basso.

Voltaggi consigliati (parametri eikon):

3V DOTWORK

5V COLORAZIONE

5.5V SFUMATURA

N.B. VOLTAGGIO MASSIMO 6V

Via dei sabelli, 70/72 - 00185 Roma

Tel. +39 06 4958114 · Whatsapp +39 328 1264531

santasangresupply@gmail.com · www.santasangresupply.com



SANTA · SANGRE · SUPPLY

COIL MACHINES

After the first 10 hours of use the machine will have settled in the tension of the spring, therefore proceed by closing the contact screw by 1/4 of a turn.

Then repeat the operation about once a month, or whenever the need is felt (coils overheating, progressive need to increase voltages).

ROTARY MACHINE SLIDER 22mm (4.5mm STROKE)

Use with clipcord positive end down.

Recommended voltages

(eikon parameters):

3V DOTWORK

5V COLORING

5.5V SHADING

N.B. MAXIMUM VOLTAGE 6V

Lubricate the slide once a month with the supplied superlube.

ROTARY MACHINE SLIDER 27mm (4.2mm STROKE)

Use with clipcord positive end down.

Recommended voltages

(eikon parameters):

3.5V DOTWORK

6.5V COLORING

7V SHADING

N.B. MAXIMUM VOLTAGE 9V

Lubricate the slide once a month with the supplied superlube.

SH808 ROTARY MACHINE (4.5mm STROKE)

Use with clipcord positive end down.

Recommended voltages

(eikon parameters):

3.5V DOTWORK

6.5V COLORING

7V SHADING

N.B. MAXIMUM VOLTAGE 9V

Lubricate the piston once a month with a technical oil (e.g. vaseline oil).

DIRECT ROTARY MACHINE 27mm (4.5mm/3.7mm STROKE)

Use with clipcord positive end down.

Recommended voltages

(eikon parameters):

3.5V DOTWORK

6.5V COLORING

7V SHADING

N.B. MAXIMUM VOLTAGE 9V

DIRECT ROTARY MACHINE 22mm (4.5mm STROKE)

Use with clipcord positive end down.

Recommended voltages

(eikon parameters):

3V DOTWORK

5V COLORING

5.5V SHADING

N.B. MAXIMUM VOLTAGE 6V

Via dei sabelli, 70/72 - 00185 Roma

Tel. +39 06 4958114 · Whatsapp +39 328 1264531

santasangresupply@gmail.com · www.santasangresupply.com